




11382 Plug for ASR-cylinder clip / set of 6



11366 Stays for suntour



11380 Protector SPB 3,0 mm 10
Stay fastening / set of 10




8315-0355
V-Stays BLUEMELS 3.0
Incl. 3 x assembly material and
stainless steel stays 3.0,
355 mm. Set of stays for front
and rear wheel.



8315-0380
V-Stays **380 mm**



10188 Clipbag



10190 Frame mounting kit