





MONKEY LINK RECHARGE

Simply upgrade your mountainbike if it is not equipped with MonkeyLink interfaces. An upgrade to the latest MonkeyLink standard is quite easy and only requires a few parts.

The lighting components in the Recharge Series are powered by electricity from the integrated battery and can be comfortably charged via an USB port.



HOW CAN I UPGRADE MY BIKE WITH ML-RECHARGE?

FRONT			REAR		
STEM OR HANDLEBAR	+	V-BASE	+	LIGHTING	
					
			SEAT CLAMPS	+	V-BASE
					
					LIGHTING OR FENDER
					