ANDROID



OPERATING INSTRUCTIONS AIRSPY → GARMIN







For users of an ANDROID smartphone:

Check in the MYBIKE app to see if a new firmware version is available. To do this, go to the AIRSPY menu. The "firmware" menu item is located at the bottom right.












Select the AIRSPY sensors one by one and start the update. Before the update of the AIRSPY sensors can be started, you need to disconnect the sensors that may be actively connected.




If the sensor named TPMS_DFU is displayed, the update has not been completed. Please select this sensor and perform the update again. The sensor is then detected again by its serial number.




First of all, note the serial numbers of the sensors. Make sure that your Garmin device is connected to your smartphone. To do this, follow the Garmin procedure.

First of all, log into the Garmin Connect app to be able to use the AIRSPY tyre pressure sensor on your Garmin device.

Go to the three blue menu bars at the top left.




Scroll down to the "Garmin devices" menu item and then select the appropriate device. Go to the "Activities & App Management" menu item and then to "Data fields".





Select the "Get More Data Fields" menu item highlighted in blue. You will be forwarded directly to the Garmin Connect IQ store.



Enter SKS AIRSPY in the search bar and download the data field.


Close the Garmin Connect IQ store.

If you are not on the "Data fields" page, repeat the steps from point 1 to point 4, if necessary. Select the SKS AIRSPY data field under the "Not installed" menu item.

Click on the button highlighted in blue and install the SKS AIRSPY data field.

Then select this to pair the sensors.

Open the "Settings" menu item and enter the previously noted AIRSPY serial numbers (front and rear).






Make sure that the sensors are activated, otherwise move them for about five seconds.

Confirm your entries with "Done".

Please proceed as follows to now create the data field on one of the training pages of your Garmin device: Start the Garmin device and go to "Settings".

Open "Ride Settings".




Select the "Data Screens" menu item.

Now add a new page or edit one of your existing training pages.




Select the "Data page" menu item.


Scroll through the data fields to the bottom and select "Connect IQ".



Put a check behind "SKS AIRSPY" and use the arrow at the bottom left to go back to the data field selecti on (point 6).

Confirm the selection with the check at the bottom right.







If you do not see any datas on the Garmin, please follow these instructions:

- 1. Check if the sensors are activated (move continuously for at least 5 seconds)
- 2. Check if the serial numbers are correctly stored in the settings.
- 3. Verify that ANT+ is enabled on your device.
- 4. Start an activity on your Garmin device. It may take a short time to display the values (5 minutes maximum).
- 5. If still no values are displayed, turn off your Garmin device and restart it.



AIRSPY → GARMIN

Approach® S60

D2™ Charlie

D2™ Delta

D2™ Delta PX

D2™ Delta S

Darth Vader™

Descent™ Mk1

Edge® 1000

Edge® 1030

Edge® 1030

Bontrager

Edge® 130

Edge® 520

Edge® 520 Plus

Edge® 530

Edge® 820

Edge® 830

Edge® Explore

Edge® Explore 1000

Edge® Explore 820

First Avenger

ForeAthlete® 735XTJ

Forerunner® 245 Forerunner® 245 Music

Forerunner® 645

Forerunner® 645 Music

Forerunner® 735XT

Forerunner® 935

Forerunner® 945

GPSMAP® 66i

GPSMAP® 66s / 66st

GPSMAP® 86i

GPSMAP® 86s

GPSMAP® 86sc

GPSMAP® 86sci

MARQ™ Adventurer

MARQ™ Athlete

MARQ™ Aviator

MARQ™ Captain

MARQ™ Commander

MARQ™ Driver

MARQ™ Expedition

Oregon® 7 Series

Rino® 7 Series

Venu

fēnix® 5

fēnix® 5 Plus fēnix® 5S

fēnix® 5S Plus

fēnix® 5X

fēnix® 5X Plus

fēnix® 6

fēnix® 6 Pro

fēnix® 6S

fēnix® 6S Pro

fēnix® 6X Pro

fēnix® Chronos

vívoactive® 3

vívoactive® 3 Mercedes-Benz® Collection

vívoactive® 3 Music

vívoactive® 4

vívoactive® HR



