




## MV-EASY-Info

Ouvert = valve non serrée



Valve serrée = pompage



①



AUTO  
SCHRADER

②



SCLAVERAND  
PRESTA

+



DUNLOP