



















Put the TL-HEAD on valve and lock the thumblock lever.



CO₂ out of the cartridge by careful counterclockwise rotation.

After using the cartridge, its possible to inflate the tyre by manual pumping.





EN. TL-HEAD-SET

Incl. 2 cartridge (16g) + 1 tyre lever set

